



the moodsign
keep the romance alive



MANUAL

The Moodsign is a unique non-verbal communication device that provides you and your partner with clear and flirtatious ways to signal your "mood", whatever it may be!

The Moodsign is designed for adults that respect one another's bodies and boundaries and are BOTH willing to try a fun new way of communicating their needs and desires.

The more clearly we share our needs and desires, whether there are sexual or getting some help around the house, the more likely they are to be met and the more connected and satisfied we feel in our relationship!

HOW TO USE

- 1. RAISE ONE ARM**
Signal that you are “in the mood” for something by raising one arm of The Moodsign. The arm height and light intensity can be adjusted to best match your “mood” or to build excitement as it goes up throughout the day!
- 2. CHOOSE A COLOR**
Select a color of your liking.
Alternatively, you and your partner could designate certain colors to mean different things so when they walk in and see it, they know just what to look forward to!
For example: colors could represent date night, a massage, making love, something new in the bedroom, or even a color for “honey I’ve got the kids tonight you go take a bath!
- 3. LEAVE A NOTE OR A GIFT (optional)**
Personalize your message or “mood” with a note.
“Foot massage?”, “will bring back a nice bottle of wine”, or “I got a new toy for the bedroom!”
You can even leave a gift next to The Moodsign, maybe some jewelry, their favorite chocolates, cologne, or some new lingerie!
- 4. CONNECT**
Connect and Make Love when the time is right!
The Moodsign helps you get in sync and never miss an opportunity to connect: make love, talk, go on a date, or do whatever you and your partner have set “the mood” to do!

Please visit:
www.themoodsign.com/how_to_use
for more information

OPERATING MANUAL

To open and light up:

Press on one side of the device, the corresponding arm will be released and will automatically light up. Pull the arm into the desired position.

To close and turn off:


Click the arm back in its folded position. The light will turn off.

To change light intensity:

Tap the bottom front of the device on the corresponding side for which you want to change the light intensity.

There are three different power levels.

Tip: batteries will last longer using lower light intensity.



To change colors:

Press the buttons on the back of the device. There are 6 available colors: Red, Blue, Green, Yellow, Pink and Orange.

Random color selection mode:

Press color selection button for more than 2 seconds, colors will cycle and stop on a random color.


This mode can be used with the Moodsign game [check our website for more information]

Note: you cannot control light intensity or arm color while random mode is running.



Batteries:

To install or replace batteries, press on the mark at the top of the battery cover and slide the cover open. Install 3 new AAA batteries. *(rechargeable batteries recommended)*



LOW BATTERY: gradual change in colors, loss of light intensity, lights flashing or impossibility to change colors or light intensity are signs of low battery.

More information at:
www.themoodsign.com/product_manual

TECHNICAL INFORMATION

BATTERIES

This product requires 3 AAA batteries to operate.
(*batteries not included*).

We recommend the use of rechargeable batteries to be more environmentally friendly.

OPERATION TIME

Normal operation time of the device:

- minimum of 2.5 days of operation with one arm lit up.
- more than 10 days with one arm up at low intensity.
(with standard quality 900mA rechargeable batteries).

Note: basic use of the Moodsign is still possible without batteries! Just raise an arm to signal your Mood!

Compliant with FCC regulations.

Please dispose of this device through an approved electronics recycler.

THIS DEVICE IS NOT A TOY.

WARRANTY

The Moodsign comes with a 3 month limited warranty from date of delivery.

Full warranty conditions can be found on The Moodsign website:

www.themoodsign.com/warranty

CONTACT INFORMATION

Please visit our website:
www.themoodsign.com

For issues about your Moodsign:
customerservice@themoodsign.com

To give us feedback about your Moodsign:
contact@themoodsign.com